checkCIF/PLATON report

Structure factors have been supplied for datablock(s) am62_lt_auto

THIS REPORT IS FOR GUIDANCE ONLY. IF USED AS PART OF A REVIEW PROCEDURE FOR PUBLICATION, IT SHOULD NOT REPLACE THE EXPERTISE OF AN EXPERIENCED CRYSTALLOGRAPHIC REFEREE.

Datablock: am62_lt_auto

Bond precision:	C-C = 0.0023 A	Wavelength=0.71073	
Cell:	a=6.9245(2) alpha=90		c=21.5135(7) gamma=90
Temperature:	151 K	31.000(3)	gamma 50
	Calculated	Reported	
Volume	1074.43(6)	1074.43(6))
Space group	P 21/c	P 1 21/c 1	
Hall group	-P 2ybc	-P 2ybc	
Moiety formula	C13 H13 N O2	C13 H13 N O2	
Sum formula	C13 H13 N O2	C13 H13 N O2	
Mr	215.24	215.24	
Dx,g cm-3	1.331	1.331	
Z	4	4	
Mu (mm-1)	0.090	0.090	
F000	456.0	456.0	
F000'	456.21		
h,k,lmax	10,10,31	9,10,30	
Nref	3444	2987	
Tmin, Tmax	0.980,0.987	0.778,1.0	00
Tmin'	0.979		
Correction method= # Reported T Limits: Tmin=0.778 Tmax=1.000 AbsCorr = MULTI-SCAN			
Data completeness= 0.867 Theta(max)= 31.060			
R(reflections) =	0.0544(2559)		wR2(reflections) = 0.1474(2987)
S = 1.082	Npar= 1	147	222.2(2307)

The following ALERTS were generated. Each ALERT has the format test-name_ALERT_alert-type_alert-level.

Click on the hyperlinks for more details of the test.

Alert level C

PLAT094_ALERT_2_C Ratio of Maximum / Minimum Residual Density 2.18 Report PLAT906_ALERT_3_C Large K Value in the Analysis of Variance 4.383 Check

Alert level G

- 0 ALERT level A = Most likely a serious problem resolve or explain
- 0 ALERT level B = A potentially serious problem, consider carefully
- 2 ALERT level C = Check. Ensure it is not caused by an omission or oversight
- 3 ALERT level G = General information/check it is not something unexpected
- O ALERT type 1 CIF construction/syntax error, inconsistent or missing data
- 2 ALERT type 2 Indicator that the structure model may be wrong or deficient
- 1 ALERT type 3 Indicator that the structure quality may be low
- 1 ALERT type 4 Improvement, methodology, query or suggestion
- 1 ALERT type 5 Informative message, check

It is advisable to attempt to resolve as many as possible of the alerts in all categories. Often the minor alerts point to easily fixed oversights, errors and omissions in your CIF or refinement strategy, so attention to these fine details can be worthwhile. In order to resolve some of the more serious problems it may be necessary to carry out additional measurements or structure refinements. However, the purpose of your study may justify the reported deviations and the more serious of these should normally be commented upon in the discussion or experimental section of a paper or in the "special_details" fields of the CIF. checkCIF was carefully designed to identify outliers and unusual parameters, but every test has its limitations and alerts that are not important in a particular case may appear. Conversely, the absence of alerts does not guarantee there are no aspects of the results needing attention. It is up to the individual to critically assess their own results and, if necessary, seek expert advice.

Publication of your CIF in IUCr journals

A basic structural check has been run on your CIF. These basic checks will be run on all CIFs submitted for publication in IUCr journals (*Acta Crystallographica*, *Journal of Applied Crystallography*, *Journal of Synchrotron Radiation*); however, if you intend to submit to *Acta Crystallographica Section C* or *E* or *IUCrData*, you should make sure that full publication checks are run on the final version of your CIF prior to submission.

Publication of your CIF in other journals

Please refer to the *Notes for Authors* of the relevant journal for any special instructions relating to CIF submission.

PLATON version of 12/09/2022; check.def file version of 09/08/2022

